Thanks for choosing the Xbox 360 120GB Hard Drive. The Xbox 360 120GB Hard Drive lets you save games, save music and create

NOTE

Because the Xbox 360 system software uses some of the memory from the hard drive, less than the stated storage capacity will be available to the user.

AWARNING

Before using this product, read this manual and the Xbox 360 console manuals for important safety and health information. Keep all manuals for future reference. For replacement manuals, go to www.xbox.com/support or call Xbox Customer Support (see "If You Need More Help").

The limited warranty covering this product is contained in the Xbox 360 Warranty manual (Volume 2) and is available online at www.xbox.com/support.

Before attaching your new 120-GB hard drive, decide whether you want to perform a one-time transfer of all content from your existing hard drive. Whether you move your existing content or not, both drives are—and will remain, even after content transfer—fully compatible with your console. However, content can only ever be moved from the smaller drive to the larger one, and only once.

NOTE

If you intend to move content from your 20-GB hard drive, do not use the 120-GB hard drive prior to performing this procedure or you will lose whatever content you have put on it.

At the end of the transfer, your 120-GB hard drive will contain every file that could be transferred, including your saved games and content downloaded from Xhox Live

Apart from this one-time option to move all content to your new drive, you cannot copy or move files from one hard drive to another, regardless of drive capacity. Except as detailed in the following procedure, only one hard drive may be connected to your console at a time.

NOTE

As with any data-transfer process, there is a risk that some or all of your data may become lost during the transfer process. If you proceed with the data-transfer process, you do so at your own risk and you agree that Microsoft is not liable for any loss of data resulting from the transfer process.

To transfer content from your 20-GB hard drive to your 120-GB hard drive:

- Turn off your console with your existing hard drive still attached.
- **2** Disconnect all accessories from the console's controller ports.

- 3 Turn on your console. Connect and turn on a controller, which you'll need during content transfer.
- 4 Connect one end of the transfer cable to your 120-GB hard drive.
- 5 Connect the other end of the transfer cable to the console's rear USB port.

IMPORTANT

Be sure to connect the transfer cable to the back port, not a port on the front of the console.

6 Insert the included Hard Drive Transfer Disc and follow the onscreen instructions.

IMPORTANT

The transfer cable connects to the 120-GB hard drive in only one orientation. Do not force the connector on. Connect the cable in the orientation shown.



NOTES

 The Xbox 360 120GB Hard Drive transfer cable is not a PC accessory. It is intended only for connecting the Xbox 360 120GB Hard Drive to an Xbox 360 console for data transfer. Damage to your PC or other USB device could occur if you connect the transfer cable to such devices. The cable functions only when used with the supplied transfer software.

- The transfer cable is intended only for transferring data from your old hard drive to your new hard drive through your console. It is not intended for long-term connection to your console, nor is it intended for use with any other USB host or device. Dispose of the cable in accordance with the Disposal of Waste Electrical and Electronic Equipment guidelines below.
- If you are signed in to Xbox Live, the transfer process will sign you out.
- The Xbox Guide is not available during content transfer.
- If the transfer is interrupted for any reason, your content will remain on your existing 20-GB hard drive. You can restart the transfer process at any time prior to completion.
 - To begin using your 120-GB hard drive after content transfer is complete, remove your 20-GB hard drive and attach your 120-GB hard drive as instructed in "Attach and Remove Your Hard Drive."

If you've a ready using a 20-GB Xbox 360 Hard Drive see "Transfer Content From an Existing Ward Drive before

Push the front of the I drive down und tab 📶

To attach Windbard drive:

July off Wir console

- grante trespand drive bay cover om your console

To rem your hard dive;

- off your console
 - Press he tab of the flont of the hard drive and rit the unit from the console.
- **t**he 3 Postion the hard dive on hard drive pay with the font) pointed (ward the
 - and (the back pointed toward the
 - back of the donsole. Place the back of the kard drive against the back of the hard drive ball. Make sure the
 - the back of the hard drive is the lip on the back of the bard drive ba

MPORTANT

Avoid touching hard prive hay contact or hard rive sonne tor contacts with

fingers or metal sects.

You can personalise your hard drive by giving it a name.

To give your hard drive a name:

- With the hard drive attached to the Xbox 360 console, select System, Memory.
- 2 Highlight your hard drive.
- 3 Choose Device Options and rename your hard drive.

Once your hard drive has been personalised, you can identify it by its new name.

You can move items on your hard drive to a memory unit. You can also free up space on your hard drive by deleting items.

To move or delete an item from your hard drive:

- With the hard drive attached to the Xbox 360 console, select
- 2 Select your hard drive.
- 3 Choose the type of item, then the specific item that you want to move to another location or delete from the hard drive.

NOTE

If you delete content originally included with your hard drive, it cannot be restored. Make sure you do not want to keep any content before deletion.

If you encounter problems, try the possible solutions indicated below.

If your hard drive is not listed as a storage device, try the following steps, in order.

Make sure the hard drive is fully inserted into the hard drive bay and looks leleomLEe



Do not attempt to take apart, service, or modify the Xbox 360 console, power supply, or its accessories in any way. Doing so could present the risk of serious injury or death from electric shock or fire, and it will void your warranty.

This symbol on the product or its packaging means that this product must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of electrical and electronic equipment. This separate collection and recycling will help conserve natural resources and prevent potential negative consequences for human health and the environment, which inappropriate disposal could cause due to the possible presence of hazardous substances in electrical

and electronic equipment. For further information about where to drop off your electrical and electronic waste, please contact your local city/ municipality office, your household waste disposal service, or the shop where you purchased this product.

Contact



weee@microsoft.com for additional information on WEEE.

Hereby, Microsoft declares that this accessory is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC with regard to the EMC Directive 89/336/EEC.

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written licence agreement from Microsoft, the furnishing of this document does not give you any licence to these patents, trademarks, copyrights, or other intellectual property.

© 2007 Microsoft Corporation, All rights reserved.

Microsoft, Xbox, Xbox 360, Xbox Live, Hexic, the Xbox logos, and the Xbox Live logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.